



RGS Rebar Version 4.0.18.a

Release Notes

Date: 12-July-2019

A) Improvements

1. **Rename** – Renamed the tab 'Std_Bend Shape_Editor' in Job Preference as '**Bend Categories**'

The screenshot displays the 'CAD Standards' application window with the 'Bend Categories' tab selected and highlighted with a red rectangle. The interface includes a top navigation bar with tabs: CAD Standards, Presentation Settings, Bar Mark, Callout, Label, Reports, Others, Range Text, and Bend Categories. Below the tabs, the 'Cad Standard File' field shows the path 'C:\Program Files\RGS\RGS Rebar 4.0\Settings Files\CAD Standards\RGS-Rebar Imperial.dwg'. The main area is divided into several sections: 'Rebar & View' (with 'Rebar' and 'View' dropdowns), 'Range' (with 'Layer', 'Start & End Block', 'Cover Layer', 'Cover Dim Style', and 'Donut Type' dropdowns), 'Elevation' (with 'Block' dropdown), 'Callout, Label & Element Mark' (with 'Callout', 'Label', 'Element Mark', and 'Bar Mark' dropdowns), 'Reports' (with 'Header Line', 'Header Data', 'Row Line', and 'Row Data' dropdowns), and 'Leader' (with 'Layer' dropdown). A 'Logo' section at the bottom right features the 'RGS REBAR' logo and a 'Browse...' button.

B) Bug Fixed

1. **Sequence of Bend shape** – Now all the Bend shapes will be displayed under 'Bend Categories' tab without repetition

